

# ANNUAL MONITORING WELL & PRIVATE SUPPLY WELL CHARTS

Inactive Exxon Facility #28077 14258 Jarrettsville Pike Phoenix, Maryland Case Number 2006-0303-BA2 Facility I.D. No. 12342

**Prepared By:** 

Kleinfelder East, Inc. 1340 Charwood Road, Suite I Hanover, MD 21076 **Prepared For:** 

ExxonMobil Environmental Services Company 7715 Crittenden Street, #309 Philadelphia, PA 19118

ONLY THE CLIENT OR ITS DESIGNATED REPRESENTATIVES MAY USE THIS DOCUMENT AND ONLY FOR THE SPECIFIC PROJECT FOR WHICH THIS REPORT WAS PREPARED.



FEDEX: 778014504804

December 22, 2016

Mr. Christopher Ralston Maryland Department of the Environment Remediation Division, Oil Control Program 1800 Washington Blvd., Suite 620 Baltimore, MD 21230-1719

RE: Annual Monitoring Well Concentration / Groundwater Elevation and Annual Private Supply Well Concentration Charts

Inactive Exxon Facility #28077 14258 Jarrettsville Pike

Phoenix, Maryland

Case Number 2006-0303-BA2

Facility I.D. No. 12342

Kleinfelder Project No.: 20163496

Dear Mr. Ralston:

Enclosed please find the annual monitoring well charts depicting groundwater elevation and MTBE (methyl tertiary butyl ether), benzene, and BTEX (benzene, toluene, ethylbenzene, and xylenes) concentrations over time. Also enclosed please find the requested Private Supply Well charts depicting MTBE (Methyl tertiary-Butyl Ether), benzene, and total BTEX (benzene, toluene, ethylbenzene, and xylenes) concentrations over time. As requested, these charts are updated and delivered annually.

As previously communicated to the MDE, the following changes have been made to the annual monitoring well and private supply well charts for 2016:

- The charts are now prepared for the most recent three year time period, rather than the full history of the project;
- Monitoring well charting has been focused on the wells reported in the monthly analytical data update;

Mr. Christopher Ralston Maryland Department of the Environment Page 2

- Private supply well charting has been focused on wells that meet specific criteria:
  - Detections of gasoline constituents above 10% of criteria in the charting timeframe
  - o Historical (pre-2008) LPH
  - Active recovery
  - Monitoring wells installed on the property
  - One property adjacent to 3627A SSA which has had a recent low-level increasing trend of MTBE

Please feel free to contact us at 410.850.0404 if you have questions or require additional information.

Sincerely,

**KLEINFELDER** 

Stacey Schiding Project Manager


CC:

Mr. John J. Hoban - Exxon Mobil Corporation (Kleinfelder File) Ms. Ellen Jackson - Maryland Department of the Environment Mr. Andrew Miller - Maryland Department of the Environment Carlos Bollar, Esquire - Archer & Greiner, P.C.




## **MONITORING WELL CHARTS**





- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) [R] indicates well was used for remediation at time of reporting.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) [R] indicates well was used for remediation at time of reporting.


# Kleinfelder






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.)HS-S = Shallow composite HydraSleeve sampler set at half of open borehole.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) HS-D = Deep composite HydraSleeve sampler set at bottom of open borehole.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) AP Sample collected above packer (packer set at 250 feet below ground surface)
- 3.)HS-S = Shallow composite HydraSleeve sampler set at half of open borehole.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) BP Sample collected below packer (packer set at 250 feet below ground surface)
- 2.) HS-D = Deep composite HydraSleeve sampler set at bottom of open borehole.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) [R] indicates well was used for remediation at time of reporting.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.)HS-S = Shallow composite HydraSleeve sampler set at half of open borehole.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.)HS-M = Middle composite HydraSleeve sampler set at middle of open borehole.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) HS-D = Deep composite HydraSleeve sampler set at bottom of open borehole.





- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sampling via custom water FLUte liners.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sampling via custom water FLUte liners.

# Kleinfelder






- 1.) Discrete interval sampling via custom water FLUte liners.
- 2.) [R] indicates well was used for remediation at time of reporting.


### Kleinfelder 1340 Charwood Road






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sampling via custom water FLUte liners.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sampling via custom water FLUte liners.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sampling via custom water FLUte liners.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sampling via custom water FLUte liners.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sampling via custom water FLUte liners.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sampling via custom water FLUte liners.





- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sampling via custom water FLUte liners.






### 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.

2.) Discrete interval sample collected at the depth indicated using a HydraSleeve sampler.

### Kleinfelder






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sample collected at the depth indicated using a HydraSleeve sampler.

### Kleinfelder






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sample collected at the depth indicated using a HydraSleeve sampler.

### Kleinfelder






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) Discrete interval sample collected at the depth indicated using a HydraSleeve sampler.

### Kleinfelder






### 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.

2.) Discrete interval sample collected at the depth indicated using a HydraSleeve sampler.

### Kleinfelder






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) AP Sample collected above packer (packer set at 300 feet below ground surface)

### Kleinfelder






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) BP Sample collected below packer (packer set at 300 feet below ground surface)

### Kleinfelder






1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.


2.) [R] - indicates well was used for remediation at time of reporting.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) [R] indicates well was used for remediation at time of reporting.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) HS-S = Shallow composite HydraSleeve sampler set at half of open borehole.






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) HS-D = Deep composite HydraSleeve sampler set at bottom of open borehole.





- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) AP Sample collected above packer (packer set at 300 feet below ground surface)
- 3.) HS-S = Shallow composite HydraSleeve sampler set at half of open borehole






- 1.) ND results are charted as "0.1" to avoid confusion with estimated "J" values.
- 2.) BP Sample collected below packer (packer set at 300 feet below ground surface)
- 3.) HS-D = Deep composite HydraSleeve sampler set at bottom of open borehole




# **PRIVATE SUPPLY WELL CHARTS**






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.





- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






1.) ND results are charted as "0" to avoid confusion with estimated "J" values.

2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.

# Kleinfelder 1340 Charwood Road Hanover, MD






1.) ND results are charted as "0" to avoid confusion with estimated "J" values.

2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.


# Kleinfelder 1340 Charwood Road Hanover, MD





- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






1.) ND results are charted as "0" to avoid confusion with estimated "J" values.

2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.


# Kleinfelder 1340 Charwood Road Hanover, MD






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.





- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.


# Kleinfelder 1340 Charwood Road





- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.


# Kleinfelder






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.
- 3.) Non-EMES POET






- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.





- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.





- 1.) ND results are charted as "0" to avoid confusion with estimated "J" values.
- 2.) BTEX = Benzene, Toluene, Ethylbenzene, and Xylenes.